

# CO<sub>2</sub>+LIGHT SENSOR

## QUICK START GUIDE

AC INFINITY

### PRODUCT WARNING

- Read all instructions before installing and using this product.
- When cutting or drilling into a wall or ceiling, do not damage electrical wiring and other hidden utilities.
- This product must not be used in potentially hazardous locations such as flammable, explosive, chemical-laden or wet atmospheres.
- Do not operate this product while its cord is damaged, or if it malfunctions, or has been dropped.

### CO<sub>2</sub> READINGS ADVISORY



Most plants need over **400ppm of CO<sub>2</sub>** to survive, with growth improving as CO<sub>2</sub> levels rise, up to 2000ppm.

Please note that you may observe high CO<sub>2</sub> readings even when not in a CO<sub>2</sub> enriched environment. This is because CO<sub>2</sub> levels can be affected by room size, how well it is sealed, how many people are in the room, and how close you are to the sensor. Indoor CO<sub>2</sub> levels will generally be higher than outdoor CO<sub>2</sub> levels.

### PRODUCT CONTENTS



CO<sub>2</sub>+LIGHT  
SENSOR  
(x1)



WOOD  
SCREWS  
(x1)



WIRE  
TIES  
(x1)

### POSITIONING THE SENSOR

#### LOCATION

Position your sensor at the canopy of your plant.


Make sure the photocell remains exposed to your light source.



## POSITIONING THE SENSOR

### HANGING


You may hang your sensor over a tent pole, or tie it onto a tent pole using wire ties.



### WALL MOUNTING


Secure the anchor into your wall. Twist the wood screw into the anchor.

Hang your sensor onto the wood screw using the mounting hole located on its backside.



## CONNECT TO YOUR CONTROLLER

Plug your sensor into the first sensor port if no other sensors are plugged in.



Only one CO<sub>2</sub>+Light sensor may be used per controller at a time. Use sensor splitters (sold separately) to pair additional ones.

## PROGRAMMING

Visit our website for controller programming.



Only compatible with specific controllers.

To set up automations and alerts, download the app.



Download on the  
App Store

GET IT ON  
Google Play

## MORE INFORMATION

### WARRANTY

WEBSITE | [www.acinfinity.com](http://www.acinfinity.com)  
EMAIL | [support@acinfinity.com](mailto:support@acinfinity.com)  
PHONE | 626-923-6399, 9 am to 5 pm PST  
ADDRESS | 21880 BAKER PARKWAY  
CITY OF INDUSTRY, CA 91789

DEALERS  
EMAIL | [dealers@acinfinity.com](mailto:dealers@acinfinity.com)  
PHONE | 626-838-4656, 9 am to 5 pm PST



MANUAL CODE COS2503X1

COPYRIGHT © 2025 AC INFINITY INC. ALL RIGHTS RESERVED

No part of the materials including graphics or logos available in this booklet may be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine readable form, in whole or in part, without specific permission from AC Infinity Inc.